


NERO™

LED States

Functions



Feed
(Blinks)


Feed
(Blinks)

All Off
(Fades Out)

All Off
(Breathes)

Resets

Button hold and
power applied




Connected
Reset

Factory
Reset

Errors

Alternating LEDS



Low
Voltage

Over
Temp

Over
Current

Motor
Fault

